



*KILLER BEES ROBOTICS*

## **KB33 FRC Competition Battery Cart**

### **Build Instructions**

Every FIRST Robotics Team needs a good battery cart.

The Killer Bees have built several battery carts over our 25-year history. This design is highly optimized for form and function.

- Compact
- Robust
- Easy to Build
- Easy to Move
- 6 Charging Ports
- 8 Battery Capacity
- Built-in Power Strip

This guide provides step-by-step build instructions for making your very own FRC Competition Battery Cart for your robotics team.

The Killer Bees Robotics Team have built several competition battery carts over our 25 year history. Shown here is a 4<sup>th</sup> generation design which has been iterated over many years. We have privately shared this with many teams, but have not published this design until now.

This design is made of plywood. A properly constructed wooden cart is actually stiffer and stronger than an un-welded metal cart.

To double check these plans and instructions, we recently built a new cart. This new unit (left) is nearly identical to its predecessor (right), which has been in service for 6 years. Apart from some scuffed paint, the original is still in great shape. We take two of these units to all of our FRC events.



This cart can be built for approx. \$100, plus the cost of the two charger units.

This design is very durable and will stand up to many years of FRC abuse.

## A few comments on materials:

- We recommend using 7 ply  $\frac{3}{4}$ " Birch Plywood for this build. The flatness and strength of furniture grade plywood is superior to construction grade materials
- We recommend the Colson wheels we have listed below. These are virtually indestructible in this high load application. The original design had FRC 8" spoked wheels, which eventually failed.
- Use a steel axle, not aluminum.
- Proper gluing of all joints is critically important.

## Required Materials List:

48" x 48" x 3/4" Birch Plywood

3 –  $\frac{3}{4}$ " x  $\frac{3}{4}$ " x 36" square stock pine. (you can also cut these pieces from the plywood sheet if you have a table saw)

1 – 2 x 4 x 24" Pine

1 - 1/2" x 24" Steel Rod <https://www.mcmaster.com/3076T34/>

2 - 8" x 1.5" Colson Wheels <https://www.mcmaster.com/2829t423>

2 - 1/2" Axle Cap Nuts <https://www.mcmaster.com/94803A050/>

1 - steel D-ring <https://www.mcmaster.com/3076T34/>

1 - Metal Power strip [https://www.amazon.com/Prime-Wire-Cable-PB801120-6-Outlet/dp/B006G69UT4/ref=sxts\\_sxw](https://www.amazon.com/Prime-Wire-Cable-PB801120-6-Outlet/dp/B006G69UT4/ref=sxts_sxw)

2 - Dual Pro RS3 Battery Charger

<https://www.andymark.com/products/battery-charger-3-bank-6-amp-dual-pro-rs3-with-sb-50a-connectors>

1-1/2" 15 Ga Nails

1-1/4" 18 Ga Nails

Titebond 2 wood glue

24" Bungee Cord

4 – 2" diameter slider discs

8 – 10-24 x 1.5" flathead screws,

8 – 10-24 nylock-nuts

1 Quart - Behr 2-in-1 Paint and Primer of your team color.

## List of tools needed.


- Circular Saw or Table Saw
- Hand Drill or Drill Press
- Drill / Driver with #2 Bit
- Router or Router table with  $\frac{1}{4}$ " Round-over bit
- Jigsaw
- Hacksaw or Cutoff Wheel
- Air Nailers (15 and 18 gauge)
- Sanding block
- Forstner bits  $\frac{3}{4}$ ", 1-1/4", 2"
- Countersink bit
- Clamps
- Hammer
- 3/8" Nutdriver
- Wood Glue Spreader
- 1.5" Paint Brush

Also check out the One-Day-Build YouTube video

<https://youtu.be/XOAfVUXOnXo>

and the Engineering Drawings and CAD model can be found

at <http://www.killerbees33.com/resources/>




Confirm panel  
is positioned  
as shown

Align point  
to bottom  
corner


**1** Install Lower Battery  
Spacer to Divider Panel.  
Attach with Glue and  
18G Nails

Align to bottom edge




Align to  
this edge

Battery  
Spacer  
Jig




**3** Install Remaining 6 Battery Spacers and Upper Spacer to Divider Panel using Spacer Jig (Shown in Blue)  
Use Glue and 18G Nails




**4** Mark Lines on Side Panel 2. Draw one line  $\frac{3}{4}$ " from bottom edge, draw second line  $\frac{3}{4}$  from back edge. These are guidelines for the spacer installation.


**5** Install Lower Spacer,  
Align point to where  
guide lines meet



**6** Install Battery  
Spacer using Spacer  
Jig. Align to vertical  
guide line. Assembly  
is mirror image of  
divider assembly





**7** Repeat Process to install 6 more spacers and Upper Spacer.



**8** Place assemblies face to face to ensure that all spacers are aligned properly before proceeding

**9** Carcass Assembly:  
Assemble Foot Plate  
to Back Plate. Foot  
mounts to bottom of  
back. Glue and Nail  
from bottom.





**11** Assemble Side Panel 2 to carcass. Attach to back and foot using glue and nails.





**13** Assemble  
Lower Shelf panel  
to carcass, Attach  
through sides and  
back



**14** Assemble  
Power Strip Panel  
and Spacer Block.  
Attach through sides  
and lower shelf.



Align to bottom edge  
of carcass

**16** Attach Upper Skid Blocks,  
Align to upper edge of side  
panels.

At this point it is  
recommended to add 1-5/8"  
deck screws to all perimeter  
joints at appox, 8" spacing  
Pilot drill all holes to avoid  
splitting

**15** Assemble Axle  
Blocks to Carcass.  
Install Axle before  
attaching blocks.  
Glue well, these are  
the most important  
joint in the design.  
Add screws from  
inside to attach the  
blocks.





**17** At this point, it is recommended that you paint your cart. It is much easier to do before the rest of the parts are installed.

We recommend a 2-in-1 Exterior Semi-Gloss Paint Primer Combo for durability and cleanability.




**18** Install Wheels, hammer on the cap nuts. Install 4 Slider Discs in pockets as indicated.






**19** Install Power Strip to mounting panel as shown.  
Install Upper Shelf Panel using screws.  
(this shelf is intended to be removable so do not glue)

Route Power Cable through narrow slot in shelf



## 20 Install Battery Chargers


Chargers using eight 10-24 flat head screws and nylock nuts.




Use Access holes in Divider to tighten nuts as needed

Route Charger Power Cables up through gap between shelves and plug into power strip






**21** Install Battery Cable Retainer Bar. Route all 6 Charging cords through the slots in the Retainer bar as shown (do not glue)




**22** Install Battery Cable Cover Panels. Using four  $\frac{3}{4}$ " screws. (Do not Glue, these are service doors)






**23** Install Tie Down Ring to foot using  $\frac{3}{4}$ " screws

Front screw is  
 $8"$  x  $3.5"$  from  
rear corner





**24** Project Completed!  
Install Batteries, and  
Retaining Bungee Cord.

Good Luck to all  
teams in the  
coming seasons!